



# MODEL# SVMR, SVMB

Stinger voltmeter, 3-digit display w/ turn-on circuit

## Wiring Schematic

- Red (power)** - wire to +12V constant source at location of desired reading  
**Black (ground)** - wire to chassis ground  
**Blue (trigger)** - wire to a +12V switched source (ignition) or to radio remote turn-on

## Cover Removal

depress both tabs located on either side to remove cover

## Mounting Options


- Option 1** - can be secured by (2) mounting holes located under cover with supplied screws  
**Option 2** - can be fastened by a piece of double sided tape  
**Option 3** - can be custom mounted by two thin strips of double side tape on front cover then back mounted for a more custom look

## Voltage Adjustment

test voltage at red and black wires on **SVMR /SVMB** with a small phillips or slotted screwdriver adjust meter to match reading from previous test.

**counterclockwise** - voltage increase

**clockwise** - voltage decreased



Stinger® 13160 56<sup>th</sup> Court Clearwater, FL 33760  
Technical Support 800.477.2267 ext. 230  
stingerelectronics.com